




Canvas 5 OCS Datasheet

Built-In I/O: 4 Digital DC Inputs, 4 Digital DC Outputs, 4 Analog Inputs

MAN1374_00_EN_CV5_DS



Part Number: HE-CV-043C-01

User Manual and Add-Ons

Find the documents via the [Documentation Search](#).

Part #	Description
MAN1372	Canvas 5 User Manual
HE-XCK	Programming Cables
HE-FBD001	Ferrite core for filtering out electrical noise.
HE200MJ2TRM	Adapter, RJ45 (8P8C) male to 8-position terminal strip.
HE-XRJ503	RJ45 to 5-pin Cable - 3ft
HE-XRJ509	RJ45 to 5-pin Cable - 9ft
HE-XRJ003	RJ45 to RJ45 Ethernet Patch Cable 3ft
HE-XRJ009	RJ45 to RJ45 Ethernet Patch Cable 9ft

Backup Battery

The Canvas 5 uses a Renata CR2032 lithium battery to run the Real Time Clock for 7-10 years.

Reference **MAN1372** for more details about the battery.

Power Supply Note

Very short dips (about 100 milliseconds) in the input power can result in outputs that are ON to remain ON for about one (1) second while the unit cycles power. Selecting a power supply that prevents these short glitches can eliminate this from happening.

Table of Contents

Part Number: HE-CV-043C-01	1
User Manual and Add-Ons	1
Backup Battery	1
Power Supply Note	1
TECHNICAL SPECIFICATIONS	2
General Specifications	2
Control and Logic	2
Display	2
Connectivity	3
USB Webcams	3
CONTROLLER OVERVIEW	4
Overview of OCS	4
Power Wiring	5
DIGITAL & ANALOG I/O SPECIFICATIONS	6
Digital DC Inputs	6
Analog Inputs	6
Digital DC Outputs	7
Analog In Tranzorb Failure	7
WIRING: INPUTS AND OUTPUTS	8
Digital Input Wiring	8
Positive Logic vs. Negative Logic	8
Digital Output Wiring	8
Analog Inputs	9
Built-In I/O Register Map for Canvas 5	10
COMMUNICATIONS	11
Serial Communication	11
DIP Switches	12
CAN Communications	12
Ethernet	12
microSD Slot	13
USB Ports	13
DIMENSIONS & INSTALLATION	14
Canvas 5 Dimensions	14
Installation Procedure	15
SAFETY & MAINTENANCE	16
Warnings	16
FCC Compliance	16
Precautions	16

TECHNICAL SPECIFICATIONS

General Specifications

Required Power (steady state)	264mA @ 10VDC (2.64W); 118.85mA @ 24VDC (2.85W)
Required Power (inrush)	20A for < 1 ms at 24VC DC Switched
Primary Power Range	10-30VDC
Required Power with Backlight @ 100%	118.85 @ 24VDC
Required Power with Backlight @ 50%	85.52mA @ 24VDC
Backlight @ 0%	83.3mA @ 24VDC
Battery	Replaceable Coin Cell
Clock Accuracy	+/-20 ppm maximum at 25°C (+/- 1 min/month)
Real Time Clock	With Battery
Relative Humidity	5%-95% non-condensing
Operating Temperature	-10°C to +60°C
Storage Temperature	-30°C to +70°C
Altitude	Up to 2000m
Rated Pollution Degree	Evaluated for Pollution Degree 2 Rating
Weight	10 oz / 271 g
Certifications (CE)	North America or Europe
Enclosure Type	Type 1, 3R, 4, 4X, 12, 12K, & 13

Control and Logic

Control Language Support	Advanced Ladder Logic; Full IEC 61131-3 Languages
Logic Program Size	2MB, Max.
Scan Rate	0.02ms/kB
Online Programming Changes	Supported in Advanced Ladder
Digital Inputs	2048
Digital Outputs	2048
Analog Inputs	512
Analog Outputs	512
General Purpose Registers	50,000 (words) Retentive; 16,384 (bits) Non-Retentive

Display

Display Type	Resistive 4.3" Touchscreen: 450cd/m ² (nits)
Resolution	WQVGA (480 x 272)
Color	65K Color
Screen Memory	22MB
User-Program Screens	1023
Backlight	White LED

Connectivity


Serial	2 (1xRS-232, 1x2-wire RS-485)
CAN	CAN 125kbps – 1Mbps
Ethernet	1 x 10Mbps/100Mbps
USB (2)	1 X Mini B for Programming. 1 X USB A for Wi-Fi, drives, cameras, and mouse
microSD	1 x SD, SDHC, SDXC (in FAT32 format)

USB Webcams

USB Webcams supported should support the UVC (USB Video class) protocol for the OCS to be able to display video. Most USB based video devices support this today. Special feature such as zoom and high definition are not supported by the OCS.

CONTROLLER OVERVIEW

Overview of OCS




- HG-734
1. Power
 2. Input Connector
 3. Output Connector
 4. CAN Port
 5. Serial Ports
 6. DIP Switches
 7. Ethernet Port
 8. microSD Slot
 9. USB A Port
 10. USB Mini-B Port

NOTE: See "Precautions" on page 16 about USB and grounding.

Power Wiring

NOTE: The Primary Power Range is 10VDC to 30VDC.



Primary Power Port Pins		
PIN	Signal	Description
1	Ground	Frame Ground
2	DC-	Input Power Supply Ground
3	DC+	Input Power Supply Voltage


DC Input/Frame

- Solid/Stranded Wire: 12-24 AWG (2.5-0.2mm²)
- Strip length: 0.28" (7mm)
- Torque, Terminal Hold-Down Screws: 4.5 – 7 in•lbs (0.50 – 0.78 N•m)

DC- is internally connected to I/O V- and CAN V-. A Class 2 power supply must be used.

Power Up

1. **Optional:** Attach ferrite core with a minimum of two turns of the DC+ and DC- signals from the DC supply that is powering the controllers.



2. Connect Pin 1 to Earth Ground
3. Apply DC power to pins 2 & 3.

DIGITAL & ANALOG I/O SPECIFICATIONS

Digital DC Inputs

Inputs per Module	4	
Commons per Module	1	
Input Voltage Range	0VDC - 24VDC	
Absolute Maximum Voltage	30VDC	
Input Impedance	10kΩ	
Input Current	Positive Logic	Negative Logic
Minimum ON Current	0.8mA	-1.6mA
Maximum OFF Current	0.3mA	-2.1mA
Minimum ON Input	8VDC	
Maximum OFF Input	3VDC	
OFF to ON Response	2ms min*	
ON to OFF Response	2ms min*	
Galvanic Isolation	None	
Logic Polarity	Positive or Negative (based on configuration)	
I/O Indication	None	
High Speed Counter	4 HSC	
Maximum Frequency	500kHz	
Connector Type	3.5mm Pluggable Cage Clamp	

*all values updated 1x per scan

Analog Inputs

Number of Channels	4
Input Signal Range	4-20mA, 0-20mA DC, 0-10VDC
Input Raw Value Range	0-32,000
Absolute Maximum Input Voltage	-0.5 to 12VDC
Galvanic Isolation	None
Input Impedance (clamped at -0.5 to 12 VDC)	mA: 50Ω V: 500kΩ
Nominal Resolution	12 Bits
Conversion Speed	All Channels Once per OCS Scan
Analog Maximum Error @ 25°C	1.5% of full scale


Digital DC Outputs

Outputs per Module	4
Commons per Module	1
Absolute Maximum Voltage	30VDC
Output Frequency	10kHz (up to 500kHz when using the HE-XHSQ add-on module)
Output Protection	Short Circuit & Overvoltage
Maximum Output Current per Point	0.5A
Maximum Total Current	2A Total Current
Maximum Output Supply	30VDC
Minimum Output Supply	10VDC
Maximum Voltage Drop at Rated Current	0.25VDC
Minimum Load	None
I/O Indication	None
Galvanic Isolation	None
OFF to ON Response	500ns min*
ON to OFF Response	500ns min*
HSC Out	500kHz Max.
Output Characteristics	Current Sourcing (Pos. Logic)

*all values updated 1x per scan

Analog In Tranzorb Failure

A common cause of Analog Input Tranzorb Failure on Analog Inputs: If a 4-20mA circuit is initially wired with loop power, but without a load, the analog input could see 24VDC. This is higher than the rating of the tranzorb. This can be solved by NOT connecting loop power prior to load connection, or by installing a low-cost PTC in series between the load and analog input.




WIRING: INPUTS AND OUTPUTS

Digital Input Wiring

Positive Logic vs. Negative Logic


The OCS can be wired for positive logic inputs or negative



Digital inputs may be wired in either a Positive Logic or Negative Logic fashion as shown. The setting in the Cscape Hardware Configuration for the Digital Inputs must match the wiring used in order for the correct input states to be registered. No jumper settings are required for Canvas 5. When used as a normal input and not for high speed functions, the state of the input is reflected in registers %I1 – %I4.

Digital inputs may alternately be specified for use with High Speed Counter functions, also found in the Hardware Configuration for Digital Inputs. Refer to the Canvas User Manual (**MAN1372**) for full details.

Digital Output Wiring




HC-245


Digital outputs are Positive Logic. If an output is turned on, the voltage supplied at the Vext terminal is applied to that output. When used as normal outputs, the state of the output may be controlled using the registers %Q1, %Q2, %Q3, and %Q4.

The first two digital outputs may alternately be specified for use as Pulse Width Modulation (PWM) or Stepper outputs. The configuration for these functions is found in the Cscape Hardware Configuration for Digital Outputs.

Analog Inputs



Raw input values for channels 1-4 are found in the registers as Integer- type data with a range from 0 – 32000. Analog inputs may be filtered digitally with the Filter Constant found in the Cscape Hardware Configuration for Analog Inputs. Valid filter values are 0-7 and act according to the following chart:



Data Values	
Input Mode:	Data Format, 12-bit INT:
0-20mA, 4-20mA	0-32000


Built-In I/O Register Map for Canvas 5

FIXED ADDRESS	I/O FUNCTION	X5
%I1	Digital Inputs	1-4
	Reserved	5-16
%Q1	Digital Outputs	1-4
	Reserved	5-16
%AI1	Analog Inputs	1-4
	Reserved	n/a

COMMUNICATIONS

Serial Communication

MJ1/2 Serial Ports



PIN	MJ1 PINS		MJ2 PINS	
	SIGNAL	DIRECTION	SIGNAL	DIRECTION
8	TXD	OUT	--	--
7	RXD	IN	--	--
6	0V	GROUND	0V	GROUND
5	+5V @ 60mA	OUT	+5V @ 60mA	OUT
4	RTS	OUT	--	--
3	CTS	IN	--	--
2	--	--	RX- / TX-	IN / OUT
1	--	--	RX+ / TX+	IN / OUT

NOTE: Refer to connector pinout on product

Two serial ports are provided via the single 8-position modular jack labeled "MJ1/2". MJ1 defaults to one of several methods available to program the controller. It may instead be specified for RS-232 communications with or without hardware handshaking, such as for Modbus Master/Slave, or to communicate to devices such as bar code scanners.


MJ2 may only be used as half-duplex (2-wire) RS-485. The most common use is for Modbus communications, either as a Modbus Master or Modbus Slave, though many other options are also available. Termination for the RS-485 port may be achieved by turning DIP switch 1 to the ON position. Only the two devices on either end of the RS-485 daisy-chain should be terminated.

DIP Switches

DIP Switches			
SWITCH	NAME	FUNCTION	DEFAULT
1	RS-485 Termination	ON = Terminated	OFF
2	CAN Termination	ON = Terminated	OFF
3	Bootload	Always OFF	OFF

The DIP switches are used to provide a build-in termination to both the MJ2 port and CAN port if needed. The termination for these ports should only be used if this device is located at either end of the multidrop/daisy-chained RS-485 network or CAN bus.

CAN Communications


 <p>HG-042</p>	CAN: Modular jack (8-position)
---	--------------------------------

CAN Pin Assignments	
PIN	SIGNAL
8	No Connection
7	Ground
6	Ground
5	No Connection
4	No Connection
3	Ground
2	CAN Data Low
1	CAN Data High

The CAN port is provided via the single 8-position modular jack labeled "CAN". It may be used to communicate with other OCS products using Horner's CsCAN protocol. Additionally, remote expansion I/O such as SmartRail, SmartBlock, OSC IO, and SmartStix may be implemented using the CsCAN protocol.

CAN port termination may be achieved by turning DIP switch 2 to the ON position. However, this should only occur if the Canvas 5 is at one end of the CAN daisy-chain (or the other). Only the two devices on either end of the CAN daisy-chain should be terminated.

Ethernet

 <p>HG-041</p>	<p>Green LED indicates link - when illuminated, data communication is available.</p> <p>Yellow LED indicates activity - when flashing, data is in transmission.</p>
---	---

10/100 Ethernet port with automatic MDI-X (crossover detection) is provided via the single 8-position modular jack labeled "LAN". Several features are available for use over Ethernet, such as WebMI, Modbus TCP/IP, Ethernet/IP, SMTP (E-mail), and more.



Ethernet configuration is done via the Cscape Hardware Configuration, though temporary Ethernet configuration may be done through the System Menu directly on the Canvas 5.

For more information on Ethernet, available features and protocols, refer to the Ethernet Supplement (**SUP0740**).

microSD Slot

A microSD card may be used for data and alarm logging, historic trending, program loading, firmware updates, and many other features. Supported types of microSD cards are SD, SDHC, and SDXC as long as the format of the card file system is FAT32. Card formatting may be done by the controller if no other means are available to do so.


USB Ports

The **USB Mini B port** is provided as one of several ways to program the Canvas 5. Drivers for Windows to recognize the controller as a virtual COM port are automatically installed with Cscape software.

The **USB A port** is provided to be able to use a thumb drive for data and alarm logging, historic trending, firmware updates, and many other purposes. Files may also be transferred between a USB thumb drive and the installed microSD card, Wi-Fi module, or USB cameras. Canvas units support USB mice and keyboards.

DIMENSIONS & INSTALLATION

Canvas 5 Dimensions



HG-246

+0.5 mm / - 0 mm Cutout Tolerance

Installation Procedure

- This equipment is panel mounted and is meant to be installed in an enclosure suitable for the environment, such that the back of the equipment is only accessible with the use of a tool.
- Requires a Class 2 Power Source.
- This equipment is suitable for use in Class I, Division 2, Groups A, B, C and D; Class II, Division 2 Groups F and G; and Class III Hazardous Locations or Non-Hazardous Locations only.

The Canvas 5 utilizes a clip installation method to ensure a robust and watertight seal to the enclosure. Follow the steps below for the proper installation and operation of the unit.

1. Carefully locate an appropriate place to mount the Canvas 5. Be sure to leave enough room at the top of the unit for insertion and removal of the microSD™ card.
2. Carefully cut the host panel per the diagram , creating a 90.5mm x 119.5mm (with a cutout tolerance of +0.5 mm / -0 mm) opening into which the Canvas 5 may be installed. If the opening is too large, water may leak into the enclosure, potentially damaging the unit. If the opening is too small, the OCS may not fit through the hole without damage.
3. Remove any burrs and or sharp edges and ensure the panel is not warped in the cutting process.
4. Install and tighten the four mounting clips (provided in the box) until the gasket forms a tight seal. For included metal mounting clips, use a torque rating of 7 to 10 in•lbs (0.8 to 1.13 N•m).
5. Connect I/O, communications cables to the serial port, USB ports, and CAN port as required.

SAFETY & MAINTENANCE

Warnings

1. To avoid the risk of electric shock or burns, always connect the safety (or earth) ground before making any other connections.
2. To reduce the risk of fire, electrical shock, or physical injury, it is strongly recommended to fuse the voltage measurement inputs. Be sure to locate fuses as close to the source as possible.
3. Replace fuse with the same type and rating to provide protection against risk of fire and shock hazards.
4. In the event of repeated failure, do **NOT** replace the fuse again as repeated failure indicates a defective condition that will **NOT** clear by replacing the fuse.
5. Only qualified electrical personnel familiar with the construction and operation of this equipment and the hazards involved should install, adjust, operate, or service this equipment.
6. Read and understand this manual and other applicable manuals in their entirety before proceeding. Failure to observe this precaution could result in severe bodily injury or loss of life.
7. **WARNING:** Battery may explode if mistreated. Do not recharge, disassemble, or dispose of in fire.
8. **WARNING:** EXPLOSION HAZARD- Batteries must only be changed in an area known to be non-hazardous.
9. **WARNING:** Do not disconnect while circuit is live unless area is known to be non-hazardous.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Precautions

All applicable codes and standards need to be followed in the installation of this product. Adhere to the following safety precautions whenever any type of connection is made to the module:

1. Connect the safety (earth) ground on the power connector first before making any other connections.
2. When connecting to the electric circuits or pulse-initiating equipment, open their related breakers.
3. Do NOT make connection to live power lines.
4. Make connections to the module first; then connect to the circuit to be monitored.
5. Route power wires in a safe manner in accordance with good practice and local codes.
6. Wear proper personal protective equipment including safety glasses and insulated gloves when making connections to power circuits.
7. Ensure hands, shoes, and floor are dry before making any connection to a power line.
8. Make sure the unit is turned OFF before making connections to terminals.
9. Make sure all circuits are de-energized before making connections.
10. Before each use, inspect all cables for breaks or cracks in the insulation. Replace immediately if defective.
11. Use copper conductors in field wiring only, 60/75°C.

12. Use caution when connecting controllers to PCs via serial or USB. PCs, especially laptops, may use “floating power supplies” that are ungrounded. This could cause a damaging voltage potential between the laptop and controller. Ensure the controller and laptop are grounded for maximum protection. Consider using a USB isolator due to voltage potential differences as a preventative measure.

Technical Support

North America	Europe
1 (317) 916-4274 1 (877) 665-5666 www.hornerautomation.com APGUSATechSupport@heapg.com	+353 (21) 4321-266 www.hornerautomation.eu technical.support@horner-apg.com