



MOTOR CONNECTION	
PIN	FUNCTION
A	—
B	W PHASE
C	—
D	—
E	GND
F	U PHASE
G	BRAKE
H	BRAKE
I	V PHASE



ENCODER CONNECTION			
PIN	FUNCTION	PIN	FUNCTION
A	A	K	—
B	\bar{A}	L	—
C	B	M	—
D	\bar{B}	N	—
E	—	P	—
F	Z	R	GND
G	\bar{Z}	S	DC+5V
H	—	T	SHIELD
J	—		



SHAFT END DETAILS

IC800VMM10LBKSE25